



1
Make sure pin is locked in receiver on vehicle.



2
If hitch is in the storage position, use hand to support hitch, pull pins and rotate.



3
Raise or lower hitch to the desired height and insert pins in holes.



4
Lock pins with cotter pins.



5
Pull the pin that unlocks the double ball, rotate to the desired size ball, insert pin in hole.



6
Lock pins with cotter pins.



7
To stow, use hand to support hitch, rotate ball to storage position, then pull pin on hitch and rotate underneath.



8
Before towing, make sure pins and balls are tight and locked with cotter pins.

Caution! Like any tool, the **TOW & STOW™** ball mount requires respect. Always use standard towing procedures and follow safety checklist (ball tight, safety chains, etc.). *Never* hook up safety chains to ball mount. *Never* overload your towing system. Always use caution when handling the **TOW & STOW™** ball mount. To avoid pinching fingers, *never* remove from receiver or carry this hitch without the locking pins in place.

For part numbers: TS10033B, TS10035B, TS10037B, TS10038B, TS10040B, TS10047B, TS10048B, TS10049B
B&W Tow & Stow 09-14-2005



B&W Trailer Hitches
1216 Hwy 224
Humboldt, KS 66748
800.248.6564
www.turnoverball.com