

Superchips Model 2905, 2906, 2907 EPROM
for GM Cars & Trucks
VEHICLE INSTALLATION INSTRUCTIONS

Your EPROM chip is inside the vehicle computer in a black rectangular carrier.

- Locate and remove the computer from the vehicle to a clean workstation.
- Remove the computer access cover.
- Remove chip and carrier

Before removing the original chip from its carrier look closely at both ends. Notice that there is a notch on the chip that is at the same end as the notch in the carrier.

Chip and carrier should disengage easily with the help of a small flat head screwdriver to gently pry it up.

To remove the stock chip from carrier:

- Simultaneously press with your finger tips into the bottom of the carrier with both hands and gently spread the sides outward.

This action should release the pins and will cause the chip to drop slightly out of the carrier. Use caution so as not to damage the delicate pins. If all the pins do not release press the chip back in and try again.

- Press with your thumbs the flexible tabs on top of the carrier to push the stock chip out.
- Install the new chip in the carrier being sure to align the notches at the same end.
- Ensure the pins are straight and lined up with the grooves of the carrier.
- Reinstall the carrier in the computer.
- Reinstall the computer in the vehicle.

Superchips suggests verifying that there are no trouble lights lit on the dash when the vehicle is started.

Use at least 91 octane fuel in the vehicle at all times.

**If you need help please contact your local dealer or call Customer Service at
407-585-7000 M-F 8:00AM-5:00PM.**