

INSTALLATION INSTRUCTIONS



MAKE: Ford
MODEL: F250 / F350
YEAR: 1999-2003
ENGINE: V8-7.3L (td)

EPBV
46-60077

	Parts Included: • EPBV	Qty. 1
CAUTION: Allow time for your vehicle to cool down prior to installation. When working on your vehicle proceed with caution. Wear protective safety equipment; eye goggles and gloves to ensure a safe installation. aFe recommends professional installation on this product.		

aFe recommends professional installation on this product.

1. Remove turbocharger from the truck.
2. Place the turbocharger on a table with the exhaust side facing up.
3. Remove the seven (7) bolts from the factory EBPV. Remove the factory EBPV from the turbocharger.
4. Clean the mating surface with a Scotch-Brite.
5. Inspect the O-rings on the turbocharger pedestal and replace if worn.
6. Install the supplied EBPV using the factory bolts and tighten to the factory torque specs.
7. Reinstall the turbocharger back on the truck.
8. Your installation is now complete. Start the vehicle to verify that all connections are secure and that you have no leaks.