



# Intake Kit Installation Instructions: '92-'00 GM Truck/SUV's V8-6.5L (td) Stage-2 Air Intake

Kit Part #	51-10732-E	Tools Required	Part List:	
Make:	GM	10mm socket or wrench	1 Filter & clamp (PN <i>Pro Dry S</i> ™ 21-40035)	2 M8 Washer, Flat
Model:	Silverado/Sierra/2500/3500/C3500 HD/Tahoe/Suburban/Yukon/Blazer	13 mm socket or wrench	2 M8 Washer, Lock	1 Trim Seal, 27"
Note:	Pick Up (Vin Code "F" - vehicles with no MAF sensors)	5/16" Nut driver	1 Molded intake tube	1 Coupling, Straight 3.25" x 2"
Engine:	V8-6.5L Turbo Diesel	Medium Flat Screwdriver	2 M6 x 25 Hex Head Screw	2 Clamp, #052
Year:	1992-2000		2 M6 Nut	1 12 oz. Cleaner Spray for <i>Pro Dry S</i>
Note: Please confirm Parts List and read all instructions steps before proceeding with actual installation.				

