

# 97759 MAP SENSOR RELOCATION KIT FOR 2007.5-2024 DODGE/RAM 2500-5500 6.7L DIESEL

INSTALL  
INSTRUCTIO  
NS  
Part #s  
64413 &  
64416



---

## Bill of Materials

Part Number	Description	QTY
43637	MAP Spacer	1
91779	T20 Stainless Torx Screw w/ Thread Locker 20mm	2
93157	High Temp O-Ring	1
93012	T20 Torx Key	1
62217	MAP Sensor Extension Harness	*1

\*MAP Sensor Extension Harness only included in 2019+ Kits

## General Installation Practices

### General Installation Practices - Show

**15  
MIN**

**NOTE:**  
Disconnect  
Battery




Before unplugging your MAP sensor, it is important to disconnect both batteries and let the ECM discharge for at least 15min.

## MAP Sensor Relocation Kit Installation




### 1. Locate MAP sensor

For pickup truck RAMs, it is found on back side of the Intake Horn.



## (Attn: Chassis Cab)

Chassis Cab and Commercial trucks, your MAP sensor may be located on the back side of the Intake Manifold Plate.



## 2. Unplug MAP sensor

Press the locking tab down, then unplug from the sensor.



## 3. Remove factory T15 Torx

This will be re used in the Banks MAP Relocation Kit.



## 4. Remove MAP sensor

Twist and lift to free it from the intake horn or manifold.



## Important: Use Mass Air Flow Cleaner Only.

Solvents such as brake cleaner will damage the sensor.




## 5. Clean MAP sensor

Try not to overly spray the sensing wire.



A rag or brush can be used for stuck-on debris.



## 6. Install O-Ring

Don't forget to install the newly supplied o-ring into the Banks MAP Spacer.



## 7. Install MAP sensor into Banks Spacer

Twist while inserting the MAP sensor to prevent O-ring damage.



Thread the factory T15 Torx screw by hand, then tighten snugly.

## 8. Reinstall the Banks MAP spacer and sensor into the intake horn or manifold plate.



## 9. Tighten the Banks MAP spacer with the supplied T20 Torx Key.



Start by hand, then use the supplied T20 Torx key.



## 9. Reconnect MAP sensor

Be sure to slide the locking tab forward into place.



## 9a. 2019+ Models

A MAP sensor extension harness is included in your kit. Use this in-line between the MAP sensor and your OEM harness.



## 10. All Done

Double-check that all bolts are snug.



Reconnect both batteries, and enjoy your new Banks MAP Sensor Reolcation Kit.