

RAM Track Bar Installation

After Installation a Professional alignment will be required

1. Both the frame side and axle side of the track bar will be torqued to 285 ft/lbs
2. The 'K' marking on the track bar will go to the frame on the driver side.
3. Once installed snug the adjustment collar will be torqued to 80 ft lbs

 **FOLLOW US**
@kryptoniteproducts

KRYPTONITEPRODUCTS.COM

Axle

285 ft/lbs



Frame

285 ft/lbs

Clamp bolts

80 ft/lbs