

INSTALL INSTRUCTIONS FOR 82-1007

BEFORE YOU START

Thank you for purchasing your new S&B Filters Map Spacer. If at any time you need additional assistance with installation or have any other questions or comments, feel free to call our customer support team at **909-947-0015**.

REQUIRED TOOLS

- 5mm Allen Wrench/Bit
- 10mm Socket with Ratchet
- Blue Loctite
- Torque Wrench (inch pounds)

Approx. Install Time: 15 min

mount the stock MAP
sensor onto the S&B MAP
Sensor spacer. Then tighten
down the stock 10mm bolt

holding the MAP Sensor to the spacer.



STEP 4:

Take the provided 5mm Allen Bolt and use this to secure the S&B Map Sensor to the manifold.

Once done, go ahead and torque both the allen and hex head bolts to 60in. lbs.



STEP 5:

Next, go ahead and plug in the MAP Sensor to the OEM

wire harness using the included extension harness within this kit.

STEP 5:

The installation is now complete.

Please verify that all connection points are tight and secure.