



2001-2019 Duramax Brake Master Cylinder Reservoir Cover


Covers installation of PN: WCF100205

Install shown on LB7




1. Loosen the two 15 mm nuts on the front of the master cylinder. If the stud starts to rotate, hold it on the back side with a wrench while loosening and tightening the nut.

2. Remove the brake fluid cap.



3. Slip the new cover between the nuts and master cylinder. Do not install between master cylinder and hydro boost.
4. Adjust the cover and torque nuts to 27 ft lbs using extension.
5. Reinstall brake fluid cap. Optional Billet Cap WCF100216 sold separately is shown in these images.



Any Questions, Comments, or Feedback?

Reach us by Email- Sales@wcfab.com

Or the shop phone- 630-277-8239

Thank you for purchasing from Wehrli Custom Fabrication!

