


PULSAR

INLINE CONTROL MODULE



FEATURE AND PROGRAMMING MENU

QUICK REFERENCE

GM GAS TRUCK/SUV



TECHNICAL SUPPORT

For operating instructions and troubleshooting, please refer to the User Guide. For additional questions contact:

MON-FRI 8:00 AM - 5:00 PM (MST)


1-888-360-3343

PN# D10027200

ACCESS

PROGRAMMING MENU (repeat for each feature)

1. Engine Off
2. a. Using a push button -
Foot off brake, Press and hold Start button 5 sec.
b. Using a key - turn key to the RUN position
3. Hold Cancel Cruise button 5 sec.
4. Navigate with +RES/-SET to feature
5. Press Cancel Cruise to select feature



Speed Limiter **10**

1. Select 10 (MPH)
2. Adjust with +RES/-SET
3. Press Cancel Cruise to select

TPMS (Tire Pressure Monitor System) **20**

1. Select 20 (MPH)
2. Adjust with +RES/-SET
3. Press Cancel Cruise to select

Tire Size **30**

1. Select 30 (MPH)
2. Select stock whole number then press Cancel Cruise to save
3. Select stock decimal number then Cancel Cruise to save
4. Repeat 2-3 with modified tire size

Axle Ratio **40**

1. Select 40 (MPH)
2. Select stock whole number then press Cancel Cruise to save
3. Select stock decimal number then Cancel Cruise to save
4. Repeat 2-3 with modified axle ratio

Clear DTC's **50**

1. Select 50 (MPH)
2. Press Cancel Cruise to select

AFM/DFM (Fuel Management) **60**

1. Select 60 (MPH)
2. Adjust with +RES/-SET
 - a. 0 = Active
 - b. 10 = Disabled
3. Press Cancel Cruise to select

* For complete instructions please refer to the user manual