

DFRM15

DODGE

Front suspension package Ensemble pour suspension avant Ensemble para suspensión de delantero

INSTALLATION INSTRUCTIONS

- Partially raise vehicle allowing access to control arm.
- Insert item #1 to upper side of pivot joint of control arm. Choose pivot joint of control arm that is located to rear side of strut. Ensure that bolt from item #1 will protrude out the frame.
- Install item #2. Ensure that brackets will be installed on correct side of vehicle.
- Secure brackets using supplied hardware.
- Install Aeon rubber spring.
- Lower vehicle.

NOTES:

Install steel disc #3 in between Aeon rubber spring and Timbren bracket, if necessary, to ensure rubber spring is in full contact when vehicle on ground.

Turn wheel full lock left and right to check for interference.

Do not exceed vehicle manufacturer's recommended axle weight rating. Check for Aeon® interference with vehicle components. Under load Aeon® will "expand" in diameter.

INSTALLATION INSTRUCTIONS

- Soulever partiellement le véhicule pour accéder au bras de commande.
- Insérez l'article #1 en haut de l'articulation pivotante du bras de commande. Assurez-vous que le boulon de l'article #1 dépasse du cadre.
- Installez l'élément #2. Assurez-vous que le support sera installé du bon côté du véhicule.
- Fixez le support à l'aide du matériel fourni.
- Installez le ressort en caoutchouc Aeon.
- Abaissez le véhicule.

REMAQUES:

Installez le disque en acier #3 entre le ressort en caoutchouc Aeon et le support Timbren, si nécessaire, pour vous assurer que le ressort en caoutchouc est en contact complet après l'installation lorsque le véhicule est au sol.

Tourner le verrou complet des roues vers la gauche et la droite pour vérifier les interférences.

Ne dépassez pas le poids recommandé par le fabricant du véhicule. Vérifiez l'interférence Aeon® avec les composants du véhicule. Sous charge, Aeon® va "se dilater" en diamètre.

INSTALLATION INSTRUCTIONS

- Elevé parcialmente el vehículo permitiendo el acceso al brazo de control.
- Inserte el ítem #1 en la parte superior de la articulación del brazo de control. Asegúrese de que el perno del elemento #1 sobresalga del marco.
- Instale el artículo #2. Asegúrese de que el soporte se instalará en el lado correcto del vehículo.
- Asegure el soporte utilizando los hardware suministrados.
- Instale el resorte de goma Aeon.
- Bajar el vehículo.

NOTAS:



Instale el disco de acero #3 entre el resorte de goma Aeon y el soporte Timbren, si es necesario, para asegurarse de que el resorte de goma esté en contacto completo después de la instalación cuando el vehículo esté en el suelo.

Gire el bloqueo completo de la rueda hacia la izquierda y hacia la derecha para verificar la interferencia.

No exceda la clasificación de peso por eje recomendada por el fabricante del vehículo. Verifique la interferencia Aeon® con los componentes del vehículo. Bajo carga, Aeon® se "expandirá" en diámetro.

Ref. = Reference = No. de référence = Núm. de referencia
Part = Part #. = No. de pièce = Núm. de pieza
Qty. = Quantity = Quantité = Cantidad

Ref	Part	Qty
1	K11032-003	2
2	K11029-003	1L-1R
3	A16250-003	2
4	A00180-65AG00	2
5	F13536-753	4
6	F30051-350	2
7	F40310-020	6



DFRM15 **TIMBREN**

PART NUMBER	DESCRIPTION	QTY	LOCATION
F30051-350	HEX NUT STD M10 x 1.50 PC 8.0 Z DIN 934	2	I1D
F40310-020	WASHER FLT M10 GR 4.6 Z DIN 125	6	I1D
F13536-753	SHCS M10-1.5 x M30 F/T PC8.8 B DIN 912	4	J1C

A00180-65AG00	HOLLOW RUBBER SPRING	2	C4A
----------------------	----------------------	----------	------------

K11029LH-003	WELDMENT LH	1	TBD
K11029RH-003	WELDMENT RH	1	TBD
K11032-003	NUT LOCATOR WELDMENT	2	TBD
A16250-003	DISC 2-1/2 OD x 13/32 ID x 3/16 THK	2	E(END)A

B90264-CF	MINI FRONT BOX - 7 x 5.25 x 4.75	1	A--D
B10000	8" x 12" BUBBLE FOR KITS	1	
B00029-010	BARCODE LABEL FOR KIT	1	

Issued: 04/27/2020

Clearance Instructions:

Rear SES Kits for Pick-Ups and Vans should have a 1/2" to 1-1/2" gap between the rubber spring and contact point when empty.

A partial load, or vehicle accessories will reduce or eliminate the gap.

Front SES kits are usually in full contact.

Medium and Heavy-Duty Trucks, Trailers and Motorhomes will be in constant contact, and have no gap.

Lifetime Warranty:

Timbren SES Kits are warranted against defects in material and workmanship, under normal use and service, for the life of the vehicle on which the kit was originally installed. The warranty is not transferable and proof of purchase is required. The warranty is limited to the replacement of the failed part.

TIMBREN will not be responsible for any labour or freight charges involved in the replacement of any product. TIMBREN shall be entitled to make its own inspection to determine the validity of the claim. TIMBREN shall not be liable nor warranty the product in the event of alteration, misuse, overload, negligence or damage caused by others.

If ride or performance of our product is unsatisfactory in any way, please call: 1-800-263-3113 or email sales@timbren.com

ASSEMBLY NOTES:

APPLY 'LEFT' LABEL TO L/H BRACKET